# **Praxair Material Safety Data Sheet**

1. Chemical Product and Company Identification					
<b>Product Name:</b>	Oxygen	Trade Name:	Oxygen		
Product Use:	Many.				
Chemical Name:	Oxygen	Synonym:	Synonym: Dioxygen		
Chemical Formula: O <sub>2</sub>		Chemical Family	Chemical Family: Permanent Gas.		
Telephone:	<b>Emergencies:</b> * 1-800-363-0042	Supplier /Manufacture:	Praxair Canada Inc. 1 City Centre Drive Suite 1200 Mississauga, ON L5B 1M2		
		Phone:	905-803-1600		
		Fax:	905-803-1682		

<sup>\*</sup>Call emergency numbers 24 hours a day only for spills, leaks, fire, exposure, or accidents involving this product. For routine information, contact your supplier or Praxair sales representative.

#### 2. Hazards Identification

# **Emergency Overview**

WARNING! High pressure, oxidizing gas. Vigorously accelerates combustion. Self-contained breathing apparatus may be required by rescue workers.

ROUTES OF EXPOSURE: Inhalation.

**THRESHOLD LIMIT VALUE:** TLV-TWA Data from 2007 Guide to Occupational Exposure Values (ACGIH). TLV-TWAs should be used as a guide in the control of health hazards and not as fine lines between safe and dangerous concentrations.

# **EFFECTS OF A SINGLE (ACUTE) OVEREXPOSURE:**

**INHALATION:** Breathing 80% or more oxygen at atmospheric pressure for more than a few hours may

cause nasal stuffiness, cough, sore throat, chest pain and breathing difficulty. Breathing oxygen at higher pressure increases the likelihood of adverse effects within a shorter time period. Breathing pure oxygen under pressure may cause lung damage and also central nervous system effects resulting in dizziness, poor coordination, tingling sensation, visual and hearing disturbances, muscular twitching, unconsciousness and convulsions. Breathing of oxygen under pressure may cause prolongation of adaptation to darkness and reduced

peripheral vision.

**SKIN CONTACT:** No harm expected.

**SKIN ABSORPTION:** No evidence of adverse effects from available information.

**SWALLOWING:** 

This product is a gas at normal temperature and pressure.

**EYE CONTACT:** 

No evidence of adverse effects from available information.

# **EFFECTS OF REPEATED (CHRONIC) OVEREXPOSURE:**

No evidence of adverse effects from available information.

### OTHER EFFECTS OF OVEREXPOSURE:

See "Notes to Physician", in the "First Aid" section.

#### **MEDICAL CONDITIONS AGGRAVATED BY OVEREXPOSURE:**

See "Notes to Physician", in the "First Aid" section.

#### SIGNIFICANT LABORATORY DATA WITH POSSIBLE RELEVANCE TO HUMAN HEALTH HAZARD EVALUATION:

None currently known.

#### **CARCINOGENICITY:**

Not listed as carcinogen by OSHA, NTP or IARC.

# 3. Composition and Information on Ingredients

COMPONENTS CAS CONCENTRATION NUMBER % by Mole

Oxygen 7782-44-7 100

### 4. First Aid Measures

#### **INHALATION:**

If inhaled, remove to fresh air. If not breathing, give artificial respiration. Keep patient warm and at rest. Get medical attention. Advise the physician that the victim has been exposed to high concentration of oxygen.

#### **SKIN CONTACT:**

No harm expected.

#### **SWALLOWING:**

This product is a gas at normal temperature and pressure.

#### **EYE CONTACT:**

No harm expected.

# **NOTES TO PHYSICIAN:**

Supportive treatment should include immediate sedation, anti-convulsive therapy if needed, and rest. Animal studies suggest that the administration of certain drugs, including phenothiazine drugs and chloroquine, increase the susceptibility to toxicity from oxygen at high concentrations or pressures. Animal studies also indicate that vitamin E deficiency may increase susceptibility to oxygen toxicity. Airway obstruction during high oxygen tension may cause alveolar collapse following absorption of the oxygen. Similarly, occlusion of the eustachian tubes may cause retraction of the eardrum and obstruction of the paranasal sinuses may produce "vacuum-type" headache. Newborn premature infants exposed to high oxygen concentrations may suffer delayed retinal damage, which can progress, to retinal detachment and blindness (retrolental fibroplasia). Retinal damage can also occur in adults exposed to 100% oxygen under greater that atmospheric pressure, particularly in individuals whose retinal circulation has been previously compromised.

All individuals exposed for only periods to oxygen at high pressure and all that exhibit overt oxygen toxicity should have ophthalmologic examination.

# 5. Fire Fighting Measures

**FLAMMABLE:** No. **IF YES, UNDER WHAT CONDITIONS?** Vigorously accelerates combustion.

# **EXTINGUISHING MEDIA:**

Vigorously accelerates combustion. Use media appropriate for surrounding fire. Water (i.e., safety shower) is the preferred extinguishing media for clothing fires.

#### PRODUCTS OF COMBUSTION:

None.

#### **PROTECTION OF FIREFIGHTERS:**

**WARNING!** Evacuate all personnel from danger area. Immediately deluge cylinders with water from maximum distance until cool; then move them away from fire area if without risk.

#### SPECIFIC PHYSICAL AND CHEMICAL HAZARDS:

Oxidizing agent, vigorously accelerates combustion. Contact with flammable materials may cause fire or explosion. Container may rupture due to heat of fire. Vapours are extremely irritating. Contact may cause burns to skin and eyes. No part of a container should be subjected to a temperature higher than 52 C. See incompatibility in Section 10. Most containers are provided with a pressure relief divice designed to vent contents when they are exposed to elevated temperature. Smoking, flames and electrric sparks in the presence of enriched oxygen atmospheres are potential explosion hazards.

### **SENSITIVITY TO IMPACT:**

Avoid impact against container.

#### **SENSITIVITY TO STATIC DISCHARGE:**

Not applicable.

#### PROTECTIVE EQUIPMENT AND PRECAUTIONS FOR FIREFIGHTERS:

Firefighters should wear self-contained breathing apparatus and full fire-fighting turnout gear.

# FLAMMABLE LIMITS IN AIR, % by volume:

LOWER: Not applicable. UPPER: Not applicable.

FLASH POINT: Not applicable.

**AUTOIGNITION TEMPERATURE:** Not applicable.

#### 6. Accidental Release Measures

#### STEPS TO BE TAKEN IF MATERIAL IS RELEASED OR SPILLED:

#### **Personal Precautions:**

WARNING!

Shut off flow if you can do so without risk. Ventilate area or move cylinder to a well-ventilated area. Remove all flammable materials from vicinity. Oxygen must never be permitted to strike an oily surface, greasy clothes, or other combustible material.

#### **Environmental Precautions:**

Discard any product, residue, disposable container, or liner in an environmentally acceptable manner, in full compliance with federal, provincial, and local regulations. If necessary call your local supplier.

# 7. Handling and Storage

#### PRECAUTIONS TO BE TAKEN IN HANDLING:

Use piping and equipment adequately designed to withstand pressures to be encountered. Ground all equipment. Store and use with adequate ventilation at all times. Use only in a closed system constructed of corrosion resistant materials. NOTE: Reverse flow into cylinder may cause rupture. Use a check valve or other protective apparatus in any lines or piping from the cylinder to prevent reverse flow. For additional information refer to CGA pamphlet P-1. (See section 16 for more details).

WHEN USED IN WELDING AND CUTTING: Read and understand the namufacturer's instructions and the precautionary label on the product. See American Standard Z49.1 "Safety in Welding and Cutting" published by the American Welding Society, P.O. Box 351040, Miami, Florida, 33135.

Note: Suitability for use as a component in underwater breathing gas mixtures is to be determined by or under the

supervision of personnel experienced in the use of underwater breathing gas mixtures. Become familiar with the effects, methods, frequency and duration of use, hazards, side effects and precautions to be taken.

#### PRECAUTIONS TO BE TAKEN IN STORAGE:

Store and use with adequate ventilation. Separate flammable cylinders from oxygen, chlorine, and other oxidizers by at least 6 m or use a barricade of non-combustible material. This barricade should be at least 1.5 m high and have a fire resistance rating of at least ½ hour. Firmly secure cylinders upright to keep them from falling or being knocked over. Screw valve protection cap firmly in place by hand. Post "No Smoking or Open Flames" signs in storage and use areas. There must be no sources of ignition. All electrical equipment in storage areas must be explosion-proof. Storage areas must meet national electric codes for Class 1 hazardous areas. Store only where temperature will not exceed 52 C. Store full and empty cylinders separately. Use a first-in, first-out inventory system to prevent storing full cylinders for long periods. For additional information refer to CGA pamphlet P-2305(for welding and cutting). See section 16.

### OTHER HAZARDOUS CONDITIONS OF HANDLING, STORAGE, AND USE:

High-pressure, oxidizing gas. Use piping and equipment adequately designed to withstand pressures to be encountered. Vigorously accelerates combustion. Keep oil, grease, and combustibles away. Store and use with adequate ventilation at all times. Close valve after each use; keep closed even when empty. Prevent reverse flow. Reverse flow into cylinder may cause rupture. Use a check valve or other protective device in any line or piping from the cylinder. When returning cylinder to supplier, be sure valve is closed, then install valve outlet plug tightly. Never work on a pressurized system. If there is a leak, close the cylinder valve. Vent the system down in a safe and environmentally sound manner in compliance with all federal, provincial, and local laws; then repair the leak. Never place a compressed gas cylinder where it may become part of an electrical circuit.

#### **RECOMMENDED PUBLICATIONS:**

Additional information on storage, handling, and use of this product is provided in **NFPA 55**: **Standard for the Storage, Use, and Handling of Compressed and Liquefied Gases in Portable Cylinders**, published by the National Fire Protection Association.

See also Praxair publication P-14-153, *Guidelines for Handling Gas Cylinders and Containers*. Obtain from your local supplier.

# 8. Exposure Controls/Personal Protection

**CAS NUMBER INGREDIENTS**  $LD_{50}$ LC<sub>50</sub> **Exposure Limits** (Species & (Rat, 4 Routes) hrs.) Not None. 7782-44-7 Oxygen Not applicable. applicable.

**THRESHOLD LIMIT VALUE:** TLV-TWA Data from 2007 Guide to Occupational Exposure Values (ACGIH). TLV-TWAs should be used as a guide in the control of health hazards and not as fine lines between safe and dangerous concentrations.

#### **IMMEDIATELY DANGEROUS TO LIFE AND HEALTH (IDLH):**

#### **VENTILATION/ENGINEERING CONTROLS:**

**LOCAL EXHAUST:** Use a local exhaust system, if necessary, to prevent increased oxygen

concentration and, in welding, to keep hazardous fumes and gases below

applicable TLVs in the worker's breathing zone.

MECHANICAL (General): General exhaust ventilation may be acceptable if it can maintain a

supply of air that is not too rich in oxygen an, during welding, can keep hazardous fumes and gases below the applicable TLVs in

the worker's breathing zone.

SPECIAL: None.

OTHER: None.

#### **PERSONAL PROTECTION:**

**RESPIRATORY PROTECTION:** None required under normal use. However, air-supplied

respirators are required while working in confined spaces with this product. For welding, use air-purifying or air-supplied respirators, as appropriate, where local or general exhaust ventilation is inadequate. Adequate ventilation must keep worker exposure below applicable TLVs for fumes, gases and other by-products of welding with oxygen. Selection should be based on the current CSA standard Z94.4 "Selection, Care, and Use of Respirators". Respirators should be approved by NIOSH and MSHA.

**EYE PROTECTION:** Wear safety glasses when handling cylinders.

**SKIN PROTECTION:** Wear work gloves when handling cylinders.

Select in accordance with the current CSA standard Z94.3, "Industrial Eye and Face Protection", and any provincial

regulations, local bylaws or guidelines.

Metatarsal shoes for cylinder handling. Protective clothing where **OTHER PROTECTIVE EQUIPMENT:** 

needed. Cuffless trousers should be worn outside the shoes. Select in accordance with the current CSA standard Z195, "Protective Foot Wear", and any provincial regulations, local

bylaws or guidelines.

9. Physical and Chemical Properties					
PHYSICAL STATE:	Gas.	FREEZING POINT:	-218.78°C (-361.8°F)	pH:	Not applicable.
BOILING POINT	-182.96°C (-297.3°F)	VAPOUR PRESSURE	Not applicable.	MOLECULAR WEIGHT:	32 g/mole
SPECIFIC GRAVITY: LIQUID ( Water = 1)	Not applicable.	SOLUBILITY IN WATER,	Negligible.		
SPECIFIC GRAVITY: VAPOUR (air = 1)	1.105 g/ml @ 21.1°C	EVAPORATION RATE (Butyl Acetate=1):	Not applicable.	COEFFICIENT OF WATER/OIL DISTRIBUTION:	Not applicable.
VAPOUR DENSITY:	0.0013 g/ml @ 21.1°C	% VOLATILES BY VOLUME:	100% (v/v).	ODOUR THRESHOLD:	Ordourless.
APPEARANCE & OI	DOUR: Colourless.	Odourless.		•	

10. Stability and Reactivity			
STABILITY:	The product is stable.		
CONDITIONS OF CHEMICAL INSTABILITY:	Compatibility with plastics should be confirmed prior to use.		
INCOMPATIBILITY (materials to avoid):	Combustible materials, asphalt, flammable materials, especially oils and greases.  Oxygen reacts with many materials.		

10 Ctability and Deagtivity

	Oxygen reacts with many materials.
HAZARDOUS DECOMPOSITION PRODUCTS:	None.
HAZARDOUS POLYMERIZATION:	Will not occur.

CONDITIONS TO AVOID: None known.

**CONDITIONS OF REACTIVITY:** 

None known.

# 11. Toxicological Information

ACUTE DOSE EFFECTS: The welding process may generate hazardous fumes and gases. See Sections 10 and 16

for additional information.

### **STUDY RESULTS:**

At atmospheric concentration and pressure, oxygen poses no toxicity hazards. At high concentrations, newborn premature infants may suffer delayed retinal damage (retrolental fibroplasia) that can progress to retinal detachment and blindness. Retinal damage may also occur in adults exposed to 100% oxygen for extended periods (24 to 48 hours) or at greater than atmospheric pressure, particularly in individuals whose retinal circulation has been previously compromised. All individuals exposed for long periods to oxygen at high pressure and all who exhibit overt oxygen toxicity should have ophthalmologic examinations.

At two or more atmospheres, toxicity to the Central Nervous System (CNS) occurs. Symptoms include nausea, vomiting, dizziness or vertigo, muscle twitching, vision changes, and loss of consciousness and generalized seizures. At three atmospheres, CNS toxicity occurs in less than two hours; at six atmospheres, in only a few minutes.

Patients with chronic obstructive pulmonary disease retain carbon dioxide abnormally. If oxygen is administered, raising their blood oxygen concentration, their breathing becomes depressed and retained carbon dioxide rises to a dangerous level.

Animal studies suggest that the administration of certain drugs, including phenothiazine drugs and chloroquine, increases the susceptibility to toxicity from oxygen at high concentrations or pressures. Animal studies also indicate that vitamin E deficiency may increase susceptibility to oxygen toxicity.

Airway obstruction during high oxygen tension may cause alveolar collapse following absorption of the oxygen. Similarly, occlusion of the eustachians tubes may cause retraction of the eardrum and obstruction of the paranasal sinuses may produce vacuum-type headache.

# 12. Ecological Information

No adverse ecological effects expected. This product does not contain any Class I or Class II ozone-depleting chemicals. The components of this mixture are not listed as marine pollutants by TDG Regulations.

# 13. Disposal Considerations

**WASTE DISPOSAL METHOD:** 

Do not attempt to dispose of residual or unused quantities. Return cylinder to supplier.

# 14. Transport Information

TDG/IMO SHIPPING NAME: Oxygen, Compressed

HAZARD CLASS: CLASS 2.2:

Non-flammable, non-corrosive a n d n o n - poisonous gas. CLASS 5.1: Oxidizing material.

**IDENTIFICATION #:** 

UN1072

PRODUCT RQ:

Any accidental release in a quantity that could pose a danger to public safety or any sustained release of 10

minutes or

**SHIPPING LABEL(s):** Special/Oxidizer with Class 2 at bottom.

Special/Oxidizer with Class 2 at bottom. **PLACARD** (When Required):

#### SPECIAL SHIPPING INFORMATION:

Cylinders should be transported in a secure position, in a well-ventilated vehicle. Cylinders transported in an enclosed, nonventilated compartment of vehicle can present serious safety hazards.

# 15. Regulatory Information

The following selected regulatory requirements may apply to this product. Not all such requirements are identified. Users of this product are solely responsible for compliance with all applicable federal, provincial, and local regulations. This product has been classified in accordance with the hazard criteria of the CPR and the MSDS contains all the information required by the CPR.

WHMIS (Canada): CLASS A: Compressed gas.

CLASS C: Oxidizing material.

This product is on the DSL list.

**International Regulations:** 

**EINECS:** Not available.

DSCL (EEC): R8- Contact with combustible material may cause fire.

International Lists: No products were found.

#### 16. Other Information

#### **MIXTURES:**

When two or more gases, or liquefied gases are mixed, their hazardous properties may combine to create additional, unexpected hazards. Obtain and evaluate the safety information for each component before you produce the mixture. Consult an Industrial Hygienist, or other trained person when you make your safety evaluation of the end product. Remember, gases and liquids have properties which can cause serious injury or death.

### **HAZARD RATING SYSTEM:**

**HMIS RATINGS:** 

HEALTH 0

FLAMMABILITY 0

PHYSICAL HAZARD 3

#### STANDARD VALVE CONNECTIONS FOR U.S. AND CANADA:

THREADED: 0-3000 psig CGA-540

3001-4000 CGA-577 4001-5500 CGA-701

**PIN-INDEXED YOKE:** CGA-870 **ULTRA-HIGH-INTEGRITY** CGA-714

**CONNECTION:** 

Use the proper CGA connections. **DO NOT USE ADAPTERS.** Additional limited-standard connections may apply. See CGA pamphlets V-1 and V-7 listed below.

Ask your supplier about free Praxair safety literature as referred to in this MSDS and on the label for this product. Further information about this product can be found in the following pamphlets published by the Compressed Gas Association, Inc. (CGA), 4221 Walney Road, 5th Floor, Chantilly, VA 20151-2923, Telephone (703) 788-2700, Fax (703) 961-1831, website: www.cganet.com.

> AV-1 Safe Handling and Storage of Compressed Gases

AV-8 Characteristics and Safe Handling of Cryogenic Liquid and Gaseous Oxygen

G-4 Oxvaen

Cleaning Equipment for Oxygen Service G-4.1 G-4.3 Commodity Specification for Oxygen

P-1

Safe Handling of Compressed Gases in Containers Characteristics and Safe Handling of Medical Gases P-2

P-14 Accident Prevention in Oxygen-Rich, Oxygen-Deficient Atmospheres

SB-8 Use of Oxy-Fuel Gas Welding and Cutting Apparatus

Compressed Gas Cylinder Valve Inlet and Outlet Connections V-1

Handbook of Compressed Gases, Fourth Edition

Praxair asks users of this product to study this MSDS and become aware of product hazards and safety information. To promote safe use of this product, a user should (1) notify employees, agents, and contractors of the information in this MSDS and of any other known product hazards and safety information, (2) furnish this information to each purchaser of the product, and (3) ask each purchaser to notify its employees and customers of the product hazards and safety information.

### **PREPARATION INFORMATION:**

**DATE:** 10/5/2007

**DEPARTMENT: Safety and Environmental Services** 

**TELEPHONE:** 905-803-1600

The opinions expressed herein are those of qualified experts within Praxair Canada Inc. We believe that the information contained herein is current as of the date of this Material Safety Data Sheet. Since the use of this information and the conditions of use of the product are not within the control of Praxair Canada Inc., it is the user's obligation to determine the conditions of safe use of the product.

Praxair Canada Inc. requests the users of this product to study this Material Data Sheet (MSDS) and become aware of product hazards and safety information. To promote safe use of this product, a user should (1) notify its employees, agents and contractors of the information on this MSDS and any product hazards and safety nformation, (2) furnish this same information to each of its customers for the product, and (3) request such customers to notify their employees and customers for the product of the same product hazards and safety information.

> Praxair and the Flowing Airstream design are trademarks of Praxair Canada Inc.

Other trademarks used herein are trademarks or registered trademarks of their respective owners.



Praxair Canada Inc. 1 City Centre Drive Suite 1200 Mississauga, ON L5B 1M2

Copyright © 2007, Praxair Technology, Inc. All rights reserved.